

North York Renovation Waste Checklist

Plan your bin around the project, not the calendar

The four North York drop-off depots

Bermondsey	188 Bermondsey Road (long hours, midweek)
Dufferin	35 Vanley Crescent (weekday daytime)
Ingram	50 Ingram Drive (extended weekday access)
Victoria Park	3350 Victoria Park Avenue (east end)

Phase-by-phase plan

1 Before demolition

Size the job honestly. Whatever volume you picture, add half again. Broken drywall and flooring trap air and fill faster than furniture.

2 Demolition week

The heaviest phase. Keep a bin on site. Load heavy material low and flat, break lumber down before it goes in.

3 Middle stretch

A slow trickle of packaging and offcuts. Flatten cardboard for curbside recycling. A bin sitting idle here is wasted money.

4 Final week

The second spike. Old appliances, furniture, wrapping and the boxes every fixture arrived in all come out at once. Bring a second bin back.

Keep these out of a mixed load

Clean concrete, brick, asphalt, soil	Own separate load, priced far cheaper
Paint, solvents, adhesives, asbestos	Never in a bin. Household hazardous waste depot

Book your bin online at binstoronto.ca/book-now | (647) 479-2152